



Volvo Bus. Driving quality of life



VOLVO BUS EUROPEAN BLUE CONTRACT

Full preventative maintenance

Volvo European Blue Contract includes:

- Full preventative maintenance

The Volvo European Blue Contract covers all necessary preventative maintenance required to keep your vehicle in peak condition. Through planned and regular inspections, we help protect your operator's licence and minimise the risk of coming to an unexpected standstill.

The service plan is individually tailored to match the specific coach operating conditions. With the Volvo European Blue Contract, the service costs are spread evenly throughout the contract period. The contract covers labour, Genuine Volvo Parts and other consumables. You know exactly what your servicing needs will cost you over the contract's duration.

Contract summary

Volvo European Blue Contract covers all services including oils, filters and greases relative to the pre-agreed Volvo service programme, which includes:

- Tachograph calibration (biennial)
- VCADS check of fault codes in vehicle control units
- Check batteries with Midtronics test tool
- Top end check-adjust valves and unit injectors for optimum performance and fuel consumption in accordance with Volvo servicing requirements

These will be carried out by any authorised Volvo coach dealer at a time agreed between the operator and the dealer

General round the vehicle and driver's area checks

- Warning and indication lights
- Fault codes
- Function check of parking heater
- Engine idling speed control in cab
- Retarder controls
- Engine start response including start systems
- Pressure regulator operation
- Compressor function and condition
- Brake system including condenser drain valve
- Parking brake and blocking valve
- Engine brake
- Gear shift linkage and clutch pedal (if applicable)
- Hinges, locks and sealing strips

Lubrication, oil and fluid level checks

- Chassis lubrication - including oil and fluid level checks
- Body lubrication - standard body specification lube items
- Change engine oil and filter
- Change gearbox oil and filter
- Change retarder oil
- Change rear axle oil
- Filter change in power steering/hydraulic cooling fan
- Air dryer function check and filter change

External checks and inspections

- Lights, wipers and washers
- Rear view mirrors and reflectors
- Air filter for air-con
- Refrigerant tank, condenser, pipes and hoses
- Air intake
- Batteries - dirt, leakage, attachment, specific gravity of battery acid, fluid level, connections and battery box
- Battery fixing and connections
- Fuel tank and breather
- Water separator for fuel system, draining of condensed water
- Tyre wear

VOLVO BUS EUROPEAN BLUE CONTRACT

Full preventative maintenance

External checks and inspections

- Lights, wipers and washers
- Rear view mirrors and reflectors
- Air intake
- Refrigerant tank, condenser, pipes and hoses
- Air filter for air conditioning
- Batteries - dirt, leakage, attachment, specific gravity of battery acid, fluid level, connections and battery box
- Battery fixing and connections
- Fuel tank and breather
- Water separator for fuel system, draining of condensed water
- Tyre wear

Engine compartment checks and inspections

- All mountings
- All electrical connections and cables
- Drive belts
- Compressor for air-con system
- Pressure testing of cooling system
- Coolant - including specific gravity
- Radiator and radiator fan
- Intercooler
- Seals, hoses, pipes and lines
- Exhaust for leakage
- Power steering
- Air flow between air intake and turbo
- Turbocharger and EP governor
- Pump coupling for injection pump (if applicable)
- Tightness on servo pump, oil lines and steering gear
- Top end checks, valves and unit injectors

Checks beneath the vehicle

- Gearbox, clutch and clutch wear
- Speedometer/tachograph sensor and joint coupling
- Retarder
- Rear axle
- Propeller shafts
- Exhaust pipe and silencer or particulate filter
- Air springs
- Anti-roll bars
- Rear shock absorbers
- Air suspension
- Chassis frame and cross-members
- Lubrication system (central lubrication)
- Compressed air lines and hoses
- Load sensing valve
- Check wheels and wheel nut torque
- Brake lining thickness

Front suspension, steering gear checks and inspection

- Gaitors and clearance for ball joints
- Steering link system
- Front shock absorbers
- Steering knuckle bearing
- Front wheel bearings
- Front wheels

Check brake performance and test drive

- Brake performance
- Engine performance
- Abnormal noise
- Driving controls

Please note: Tyre supply and replacement is not included

Volvo options*

The following options are available but not included within the standard contract

- * Collection or delivery of the vehicle for routine servicing or inspections
- * Servicing outside normal working hours

Volvo retains the right to alter the product's specifications without prior notification. Terms and conditions apply.

Excludes: Damage, misuse, abuse and vandal damage

VOLVO

Volvo Bus

Wedgnock Lane, Warwick, CV34 5YA
www.volvobus.co.uk